

Stop-day activities Nov 1, 2016

Coordinated by Teun. Preferred end time 15:00.

Systems

No-Break

All equipment in rack D1 will be put on no-break power. Involved machines:

```
1u ccu099
1u sas099
1u mcu099
1u
1u ldb001 (powered off)
1u ldb002
1u
1u ldb003
1u lcs120 (Virtual machines: ccu002 kdcprod lcs158 mcu002 mcu005 mcu006
scu001 scu099 smu002)
1u lcs121
1u lcs122
1u
8u lse021 (powered off)
8u lse024
8u lexar001
8u lexar002
1u lfe001
```

cep2

- Swap locus095 and locus080 physically (Done by Kees)

Cobalt

- Reset idrac
- Reboot

CEP3

- Do a filesystem check on /data of lof001-022 (Done by Robin)
- Reboots

CEP4

- ?

Software updates

MAC/SAS

- Take into production by Arno: MCU002 (CentOS7)
- Take into production by Arno: CCU002 (CentOS7)

CEP2

- none

CEP3

- none

CEP4

- none

From:
<https://www.astron.nl/lofarwiki/> - **LOFAR Wiki**

Permanent link:
https://www.astron.nl/lofarwiki/doku.php?id=public:stopdayactivities_1nov2016&rev=1477385572

Last update: **2016-10-25 08:52**

